

Top Hole Install Chart for Traverse Rods

This chart will position the bracket so the drapery will clear the floor approximately 1/2".

1. Find your Kirsch® product in the left hand column.
2. Select the correct header style.
3. Determine the desired finished drapery length.
4. Add or subtract number in the top hole column from the drapery's finished length to determine how high to measure for the top hole of the bracket.

Definitions:

Top Hole – The top or the highest hole on a Kirsch® bracket.

Floor to Ceiling Deduction – Identifies the deduction needed to account for rod in floor to ceiling draperies.

Pin Set – The position of the pin on a drapery header.

	PLEATED (ANY VARIETY)		Suggested Pin Set	RIPPLEFOLD™ (ANY FULLNESS)	
	Top Hole for Wall Mount	Floor to Ceiling Deduction		Top Hole	Floor to Ceiling Deduction
DECORATIVE TRAVERSE RODS					
2" ESTATE™ WOOD TRENDS™	+ 7/8"	- 3 3/4"	1/2"	+ 7/8"	- 3 3/4"
2" ESTATE™ DESIGNER METALS™	+ 7/8"	- 3 3/4"	1/2"	+ 7/8"	- 3 3/4"
BASIC TRAVERSE RODS					
SUPERFINE - WALL MOUNT	+ 1 3/4"	- 1/8"	1 1/2"	N/A	N/A